


FLUIDRA
PRO

USER DELEGATION

GIVE ***YOUR*** WORKFORCE
ACCESS TO JXiQ™ DIAGNOSTICS
ON FLUIDRA® PRO!

**AS A FLUIDRA® REWARDS MEMBER
YOU HAVE ACCESS TO THE
FLUIDRA PRO APP.**


**HOWEVER, YOUR TEAM WILL NEED
ACCESS AS WELL SO THEY CAN
VIEW JXiQ™ DIAGNOSTICS WHEN
THEY'RE ON-SITE.**




HERE'S HOW YOU CAN
AUTHORIZE ACCESS
TO YOUR TEAM

FLUIDRA® REWARDS MEMBER STEPS


1. Log into your Fluidra Rewards account by visiting FluidraPro.com




2. At the top left corner of your screen, left click on the ☰ menu symbol
3. Next, left click to select **“User Management”**



4. Click “Add New User”



5. Fill in the **Name**, **Email** and a **Username** for the employee you would like to share access with (we suggest using a common username formula like First Initial Last Name ex. *JSmith* or their company email address ex. *JSmith@BobsPools.com*)




6. Once filled out, click “Save User”


The employee will now receive an email and must carry out the rest of the log-in steps to get access.
Be sure to provide them with the username you assigned to them

POOL TECH STEPS


1. Check your email for a “Welcome to Fluidra Pro” message. Once opened, click on “Create Password”




2. You will be taken to the **Forgot Password** page where you will **Create** your password. Once you have created your password and confirmed it, click **Submit**




- Now you need to **download the Fluidra Pro app** from the Apple App Store or Google Play on your phone




- Once downloaded, open the app and log in using your **Username** and **Password**



5. You're in! Now tap the **"Resources"** button on the bottom right corner. This will open to the **Resource Center** where you can view each JXiQ™ Heater on your route



6. To view a JXiQ heater's diagnostic readout on-site, first select the **Jandy® JXiQ** you're servicing. *You can only connect to a Jandy JXiQ when you are within 200 feet*




7. You will be asked to enter a **6-digit PIN** when you connect to the heater for the first time. 8. To get the **PIN** number, hold down the **“MENU”** button on the heater’s digital display for 5 seconds




9. A **6-digit PIN** will appear at the top right corner of the screen




Now, enter the **6-digit PIN** in the Fluidra Pro app



10. Now you are ready to commission and service the Jandy® JXiQ™





11:43 98

< Back JX10 diagnostics

HEATER STATUS	
Heater mode	Off
Heater status	No Demand
Heater Set Temp	102°
Time to temp	0h 00m
Remote status	Stand Alone
Gas valve on time	0h 04m
Total cycles	5
Incoming Voltage	122.7 V
Transformer Voltage	23.6 V
PRE-IGNITION	
Onboard air temp	83°
Inlet water temp	52°
Outlet water temp	67°
Gas pressure	Good
SAFETY LOOP	

FluidraPro.com | 1.800.822.7933

©2024 Fluidra. All rights reserved. The trademarks and trade names used herein are the property of their respective owners. Apple and the Apple logo are trademarks of Apple, Inc., registered in the U.S. and other countries. App Store is a service mark of Apple, Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google LLC. 74557_SA